

Attachment 1 Photo documentation




Figure 1 Front view




Figure 2 Rear view



Figure 3 Bottom view




Figure 4 Power board component side view




Figure 5 Power board solder side view




Figure 6 Output, communication board component side view




Figure 7 Output, communication board solder side view



Figure 8 Front of filter board




Figure 9 The back of the filter board



Figure 10 HYD 4600-EP, HYD 5000-EP, HYD 6000-EP capacitor plate front




Figure 11 Back of HYD 4600-EP, HYD 5000-EP, HYD 6000-EP capacitor plate




Figure 12 HYD 3000-EP, HYD 3680-EP, HYD 4000-EP capacitor plate front




Figure 13 Back of HYD 3000-EP, HYD 3680-EP, HYD 4000-EP capacitor plate




Figure 14 Front of the display




Figure 15 The back of the display



Figure 16 Grounded




Figure 17 Empty case



Figure 18 HYD 4600-EP, HYD 5000-EP, HYD 6000-EP inside the machine




Figure 19 HYD 3000-EP, HYD 3680-EP, HYD 4000-EP inside the machine




Figure 20 Overall height of the machine