





**BUREAU
VERITAS**

Reference No.: 200320N024-2

Enclosure front view: SOFAR 20000TL-G2



Enclosure rear view: SOFAR 20000TL-G2






**BUREAU
VERITAS**

Reference No.: 200320N024-2

Enclosure front view: SOFAR 25000TL-G2



Enclosure rear view: SOFAR 25000TL-G2





**BUREAU
VERITAS**

Reference No.: 200320N024-2

Enclosure front view: SOFAR 30000TL-G2, SOFAR 33000TL-G2



Enclosure rear view: SOFAR 30000TL-G2, SOFAR 33000TL-G2





**BUREAU
VERITAS**

Reference No.: 200320N024-2

Enclosure terminal view: SOFAR 2000TL-G2



Enclosure terminal view: SOFAR 2500TL-G2





**BUREAU
VERITAS**

Reference No.: 200320N024-2

Enclosure terminal view: SOFAR 3000TL-G2, SOFAR 3300TL-G2



AC output terminal






**BUREAU
VERITAS**

Reference No.: 200320N024-2

Internal view: SOFAR 20000TL-G2



Internal view: SOFAR 25000TL-G2






**BUREAU
VERITAS**

Reference No.: 200320N024-2

Internal view: SOFAR 30000TL-G2, SOFAR 33000TL-G2



Main board-component side view: SOFAR 20000TL-G2, SOFAR 25000TL-G2







**BUREAU
VERITAS**

Reference No.: 200320N024-2

Main board- solder side view: SOFAR 20000TL-G2, SOFAR 25000TL-G2



Main board-component side view: SOFAR 30000TL-G2, SOFAR 33000TL-G2







**BUREAU
VERITAS**

Reference No.: 200320N024-2

Main board- solder side view: SOFAR 3000TL-G2, SOFAR 33000TL-G2




Display board-component side view






Display board-solder side view




Control board- component side view






Control board- solder side view




AC output board- component side view: SOFAR 20000TL-G2, SOFAR 25000TL-G2






AC output board-solder side view: SOFAR 20000TL-G2, SOFAR 25000TL-G2




AC output board- component side view: SOFAR 30000TL-G2, SOFAR 33000TL-G2






AC output board-solder side view: SOFAR 30000TL-G2, SOFAR 33000TL-G2




Input board-component side view






Input board-solder side view



Communication board-component side view







BUREAU VERITAS

Reference No.: 200320N024-2

Communication board-solder side view



Junction board-component side view: SOFAR 25000TL-G2, SOFAR 30000TL-G2, SOFAR 33000TL-G2






**BUREAU
VERITAS**

Reference No.: 200320N024-2

**Junction board-solder side view:
SOFAR 25000TL-G2, SOFAR 30000TL-G2, SOFAR 33000TL-G2**



Earth connection terminal

