



中国认可 国际互认 检测 TESTING CNAS L6791

Test Report issued under the responsibility of:



TEST REPORT IEC 62109-2

Safety of Power Converter for use in Photovoltaic Power Systems Part 2: Particular requirements for inverters

Report Number:	BL-DG2060127-B01 attachment 1
Date of issue:	July 02, 2020
Total number of pages	23
Name of Testing Laboratory preparing the Report	Shenzhen BALUN Technology Co., Ltd
Applicant's name:	Shenzhen SOFAR SOLAR Co., Ltd.
Address:	401, Building 4, AnTongDa Industrial Park, District 68, XingDong Community, XinAn Street, BaoAn District, Shenzhen, China.
Test specification:	
Standard:	IEC 62109-2:2011
Test procedure:	Test report
Non-standard test method:	N/A
Test item description:	Hybrid Inverter
Trade Mark:	5 FAR
Manufacturer:	Same as the applicant
Model/Type reference:	HYD 10KTL-3PH, HYD 15KTL-3PH, HYD 20KTL-3PH, HYD 5KTL-3PH, HYD 6KTL-3PH, HYD 8KTL-3PH
Ratings:	See copy of marking label and model list.
Testing Laboratory:	Shenzhen BALUN Technology Co., Ltd
Testing location/ address:	Room 104, 204, 205, Building 1, No. 6, Industrial South Road, Songshan Lake District, Dongguan, Guangdong, China
Tested by (name, function, signature)	Colin Chen /Engineer Colin Chen
Approved by (name, function, signature):	Simon Qi /Chief Engineer

-Note: The only difference between the EUT (test samples in this report) and testing sample of report BL-DG2030075-B01 attachment 1, which was issued by Shenzhen BALUN Technology Co., Ltd. on May 25, 2020 as below:

1. Add three new models: HYD 5KTL-3PH, HYD 6KTL-3PH, HYD 8KTL-3PH.

And others hardware circuit and software were all the same. So the all test data originate from the report BL-DG2030075-B01 attachment 1, which was issued by Shenzhen BALUN Technology Co., Ltd. on May 25, 2020

Page 2 of 23 Report No.: BL-DG2060127-B01 attachment 1

List of Attachments (including a total number of	pages in each attachment):
See report BL-DG2060127-B01.	
Summary of testing:	
Tests performed (name of test and test clause):	Testing location:
4.4.4.15.1 Fault-tolerance of residual current monitoring	See report BL-DG2060127-B01.
4.4.4.15.2 Fault-tolerance of automatic disconnecting means	
4.4.4.17 Cooling system failure – Blanketing test	
4.8.2 Array insulation resistance detection for inverters for ungrounded and functionally grounded arrays	
4.8.3 Array residual current detection	
4.8.3.5 Protection by residual current monitoring	
Remark:	
- Other testing conditions considered in this test report, see General product information of the report BL-DG2060127-B01 for details.	
Summary of compliance with National Difference	es (List of countries addressed):
List of countries addressed: See report See report B	L-DG2060127-B01.





Copy of marking plate:
See report BL-DG2060127-B01.



Page 4 of 23 Report No.: BL-DG2060127-B01 attachment 1

Test item particulars:		
Equipment mobility:	☐ movable ☐ hand-held ☐ stationary ☐ fixed ☐ transportable ☐ for building-in	
Connection to the mains:	☐ pluggable equipment ☐ direct plug-in ☐ for building-in	
Enviromental category::	⊠ outdoor ☐ indoor ☐ indoor unconditional conditional	
Over voltage category Mains:		
Over voltage category PV:		
Mains supply tolerance (%):	According to specified supply range	
Tested for power systems:	TN	
IT testing, phase-phase voltage (V):	N/A	
Class of equipment:	⊠ Class I	
Mass of equipment (kg):	See model list	
Pollution degree:	PD3(Inside PD2)	
IP protection class:	IP65	
······································		
Possible test case verdicts:		
- test case does not apply to the test object:	N/A	
- test object does meet the requirement:	P (Pass)	
- test object does not meet the requirement:	F (Fail)	
Testing:		
Date of receipt of test item:	See report BL-DG2060127-B01	
Date (s) of performance of tests:	See report BL-DG2060127-B01	
General remarks:		
	anded to the venet	
"(See Enclosure #)" refers to additional information appended to the report. "(See appended table)" refers to a table appended to the report. The tests results presented in this report relate only to the object tested. This report shall not be reproduced except in full without the written approval of the testing laboratory. List of test equipment must be kept on file and available for review. Additional test data and/or information provided in the attachments to this report. Throughout this report a comma / point is used as the decimal separator.		
Manufacturer's Declaration per sub-clause 4.2.5 of IECEE 02:		
The application for obtaining a CB Test Certificate includes more than one factory location and a declaration from the Manufacturer stating that the sample(s) submitted for evaluation is (are) representative of the products from each factory has been provided	☐ Yes ☑ Not applicable	

Report No.: BL-DG2060127-B01 attachment 1

When differences exist; they shall be identified in the General product information section.

Name and address of factory (ies).....

See report BL-DG2060127-B01

General product information:

See report BL-DG2060127-B01

Throughout the test report following abbreviations may be used:

cl clearance
 dcr creepage distance
 dti distance through insulation
 PCE Power Conversion Equipment
 int internal distance open-circuit
 o-c open-circuit
 o-l overload
 s-c short-circuit

BI basic insulation
 DI double insulation
 SI supplementary insulation
 RI reinforced insulation



		IEC 62109-2		
Clause	Requirement + Test		Result - Remark	Verdict

4	GENERAL TESTING REQUIREMENTS		Р
4.4.4	Single fault conditions to be applied		Р
4.4.4.15	Fault-tolerance of protection for grid-interactive inverters		Р
4.4.4.15.1	Fault-tolerance of residual current monitoring according to 4.8.3.5: the residual current monitoring	See appended table 4.4.4.15.1	Р
	system operates properly		
	a) The inverter ceases to operate		<u>P</u>
	- Indicates a fault in accordance with §13.9		<u>P</u>
	- Disconnect from the mains		<u>P</u>
	 not re-connect after any sequence of removing and reconnecting PV power 		P
	 not re-connect after any sequence of removing and reconnecting AC power 		Р
	 not re-connect after any sequence of removing and reconnecting both PV and AC power 		Р
	b) The inverter continues to operate		Р
	 the residual current monitoring system operates properly under single fault condition 		Р
	- Indicates a fault in accordance with §13.9		Р
	c) The inverter continues to operate regardless of loss of residual current monitoring functionality		Р
	not re-connect after any sequence of removing and reconnecting PV power		Р
	not re-connect after any sequence of removing and reconnecting AC power		Р
	not re-connect after any sequence of removing and reconnecting both PV and AC power		Р
	- Indicates a fault in accordance with §13.9		Р
4.4.4.15.2	Fault-tolerance of automatic disconnecting means		P
4.4.4.15.2 .1	The means provided for automatic disconnection of a grid-interactive inverter from the mains shall:		Р
	disconnect all grounded current-carrying conductors from the mains		Р
	disconnect all ungrounded current-carrying conductors from the mains		Р
	be such that with a single fault applied to the disconnection means or to any other location in the inverter, at least basic insulation or simple separation is maintained between the PV array and the mains when the disconnecting means is intended to be in the open state.	See appended table 4.4.4.15.2 Fault-tolerance of automatic disconnecting	Р
4.4.4.15.2 .2	Design of insulation or separation complies with requirements of 7.3.7 of Part 1: report here Part 1 comment and verdict.		Р
4.4.4.15.2 .3	For non-isolated inverter, automatic checking of the isolation provided by a disconnect means after single fault.	See appended test table 4.4.4.15.2 Fault-tolerance of automatic disconnecting.	Р
	If the check fail: - any still-functional disconnection means shall be left in the open position	adiomatic disconnecting.	Р



	IEC 62109-2		
Clause	Requirement + Test	Result - Remark	Verdict
		1	
	 at least basic or simple separation shall be maintained between the PV input and the mains 		Р
	- the inverter shall not start operation		Р
	- the inverter shall indicate a fault in accordance with 13.9		Р
4.4.4.16	A stand-alone inverter with a transfer switch to transfer AC loads from the mains or other AC bypass source to the inverter output:	The PCE haven' such device	N/A
	- shall continue to operate normally		N/A
	- shall not present a risk of fire as the result of an out-of- phase transfer		N/A
	- shall not present a risk of shock as the result of an out- of-phase transfer		N/A
	- And having control preventing switching: components for malfunctioning:		N/A
4.4.4.17	Cooling system failure – Blanketing test No hazards according to the criteria of sub-clause 4.4.3 of Part 1 shall result from blanketing the inverter This test is not required for inverters restricted to use only in closed electrical operating areas.	See appended test table Cooling system failure – Blanketing test.	Р
	Test stop condition: time duration value or stabilized temperature		Р
4.7	ELECTRICAL RATINGS TESTS		Р
4.7.4	Stand-alone Inverter AC output voltage and frequency		P
4.7.4.1	General General		P
4.7.4.2	Steady state output voltage at nominal DC input The steady-state AC output voltage shall not be less than 90 % or more than 110 % of the rated nominal voltage with the inverter supplied with its nominal value of DC input voltage.		P
4.7.4.3	Steady state output voltage across the DC input range The steady-state AC output voltage shall not be less than 85 % or more than 110 % of the rated nominal voltage with the inverter supplied with any value within the rated range of DC input voltage.		Р
4.7.4.4	Load step response of the output voltage at nominal DC input The AC output voltage shall not be less than 85 % or more than 110 % of the rated nominal voltage for more than 1,5 s after application or removal of a resistive load.		Р
4.7.4.5	Steady state output frequency The steady-state AC output frequency shall not vary from the nominal value by more than +4 % or -6 %.		Р
4.7.5	Stand-alone inverter output voltage waveform		Р
4.7.5.1	General		Р
4.7.5.2	The AC output voltage waveform of a sinusoidal output stand-alone inverter shall have a total harmonic distortion (THD) not exceeding of 10 % and no individual harmonic at a level exceeding 6 %.	Max. THD: 4.2%	Р
4.7.5.3	Non-sinusoidal output waveform requirements	The PCE is sinusoidal output waveform type	N/A



Page 8 of 23

	IEC 62109-2		
Clause	Requirement + Test	Result - Remark	Verdict

4.7.5.3.1	General		N/A
4.7.5.3.2	The total harmonic distortion (THD) of the voltage waveform shall not exceed 40 %.		N/A
4.7.5.3.3	The slope of the rising and falling edges of the positive and negative half-cycles of the voltage waveform shall not exceed 10 V/µs measured between the points at which the waveform has a voltage of 10 % and 90 % of the peak voltage for that half-cycle.		N/A
4.7.5.3.4	The absolute value of the peak voltage of the positive and negative half-cycles of the waveform shall not exceed 1,414 times 110 % of the RMS value of the rated nominal AC output voltage.		N/A
4.7.5.4	Information requirements for non-sinusoidal waveforms The instructions provided with a stand-alone inverter not complying with 4.7.5.2 shall include the information in 5.3.2.6.		N/A
4.7.5.5	Output voltage waveform requirements for inverters for For an inverter that is intended only for use with a know following requirements may be used as an alternative to in 4.7.5.2 to 4.7.5.3.	n dedicated load, the	N/A
	The combination of the inverter and dedicated load shall be evaluated to ensure that the output waveform does not cause any hazards in the load equipment and inverter, or cause the load equipment to fail to comply with the applicable product safety standards.	See attached document: 4.7.5.5 Evaluation of inverter for dedicated load	N/A
	The inverter shall be marked with symbols 9 and 15 of Table C.1 of Part 1.		N/A
	The installation instructions provided with the inverter shall include the information in 5.3.2.13.		N/A
4.8	ADDITIONAL TESTS FOR GRID-INTERACTIVE INVERTE	RS	Р
4.8.1	General requirements regarding inverter isolation and array grounding		N/A
	- Type of Array grounding supported:		N/A
	- Inverter isolation:		N/A
4.8.2	Array insulation resistance detection for inverters for ungrounded and functionally grounded arrays	(See attached table)	Р
4.8.2.1	Array insulation resistance detection for inverters for ungrounded arrays	See below.	Р
	Inverter shall have means to measure DC insulation resistance from PV input (array) to ground before starting operation		Р
	Or Inverter shall be provided with instruction in accordance with 5.3.2.11.		Р
	Measured DC insulation resistance:		Р
	Inverter measurement circuit shall be capable of detecting insulation resistance below the limit value R= Vmax/30mA under normal conditions		Р
	Inverter measurement circuit shall be capable of detecting insulation resistance below the limit value R= Vmax/30mA with ground fault in the PV array		Р
	Isolated inverters shall indicate a fault if the insulation		Р



Page 9 of 23 IEC 62109-2 Verdict Clause Requirement + Test Result - Remark

	resistance is less than the limit value		
	Isolated inverter fault indication maintained until insulation resistance has recovered to a value higher than the limit value	Non-isolated inverter	N/A
	Non-isolated inverters, or inverters with isolation not complying limits in the minimum inverter isolation requirements in Table		Р
	- shall indicate a fault in accordance with 13.9		Р
	- shall not connect to the mains		Р
4.8.2.2	Array insulation resistance detection for inverters for functionally grounded arrays	Inverters connected to ungrounded arrays.	N/A
	a-1)The value of the total resistance, including the intentional resistance for array functional grounding, the expected insulation resistance of the array to ground, and the resistance of any other networks connected to ground (for example measurement networks) must not be lower than R = (VMAX PV/30 mA) ohms.		N/A
	a-2) The installation instructions shall include the information required in 5.3.2.12.		N/A
	b-1) As an alternative to a), or if a resistor value lower than in a) is used, the inverter shall incorporate means to detect, during operation, if the total current through the resistor and any networks (for example measurement networks) in parallel with it, exceeds the residual current values and times in Table 31		N/A
	b-2) Inverter shall either disconnect the resistor or limit the current by other means:		N/A
	b-3) If the inverter is a non-isolated inverter, or has isolation not complying with the leakage current limits in the minimum inverter isolation requirements in Table 30, it shall also disconnect from the mains.		N/A
	c) The inverter shall have means to measure the DC insulation resistance from the PV input to ground before starting operation, in accordance with 4.8.2.1.		N/A
4.8.3	Array residual current detection		Р
4.8.3.1	General		Р
4.8.3.2	30 mA touch current type test for isolated inverters	See appended table 4.8.3.2 30mA touch current type test for isolated inverters	Р
4.8.3.3	Fire hazard residual current type test for isolated inverters	See appended table 4.8.3.3 Fire hazard residual current type test for isolated inverters	Р
4.8.3.4	Protection by application of RCD's	Not used.	N/A
	- The requirement for additional protection in 4.8.3.1 can be met by provision of an RCD with a residual current setting of 30 mA, located between the inverter and the mains		N/A
	The selection of the RCD type to ensure compatibility with the inverter must be made according to rules for RCD selection in Part 1.		N/A
	- The RCD provided integral to the inverter, or		N/A
	The RDC provided by the installer if details of the rating, type, and location for the RCD are given in the		N/A



	installation instructions per 5.3.2.9.		
4.8.3.5	Protection by residual current monitoring	RCMU used for monitoring the residual current.	Р
4.8.3.5.1	General	the residual current.	Р
7.0.3.3.1	Where required by Table 30, the inverter shall provide		<u>'</u> P
	residual current monitoring that functions whenever the		'
	inverter is connected to the mains with the automatic		
	disconnection means closed.		
	The residual current monitoring means shall measure the		Р
	total (both a.c. and d.c. components) RMS current.		•
	As indicated in Table 30 for different inverter types, array		Р
	types, and inverter isolation levels, detection may be		•
	required for excessive continuous residual current,		
	excessive sudden changes in residual current, or both,		
	according to the following limits:		
	a) Continuous residual current: The inverter shall disconnect	within 0.3 s and indicate a fault	Р
	in accordance with 13.9 if the continuous residual current ex		•
	- maximum 300 mA for inverters with continuous ouput		Р
	power rating ≤30kV;		•
	- maximum 10 mA per kVA of rated continuous output		N/A
	power for inverters with continuous output power		14// (
	rating > 30 kVA.		
	The inverter may attempt to re-connect if the array		Р
	insulation resistance meets the limit in 4.8.2.		•
	b) Sudden changes in residual current: The inverter shall		Р
	disconnect from the mains within the time specified in		•
	Table 31		
	The inverter indicates a fault in accordance with 13.9, if a		Р
	sudden increase in the RMS residual current is detected		
	exceeding the value in the table.		
	The inverter may attempt to re-connect if the array		Р
	insulation resistance meets the limit in 4.8.2.		
4.8.3.5.2	Test for detection of excessive continuous residual	See appended test table	Р
	current: test repeated 5 times and time to disconnect	4.8.3.5.2 Test for detection of	
	shall not exceed 0,3 s.	excessive continuous residual	
	,	current	
4.8.3.5.3	Test for detection of sudden changes in residual		Р
	current repeated 5 times and each of the 5 results shall		
	not exceed the time limit indicated in for each row		
	(30mA, 60mA and150mA) of Table 31.		
4.8.3.6	Systems located in closed electrical operating areas	Not specified to be located in	N/A
		closed electrical operating	
		area.	
	The protection against shock hazard is not required if		N/A
	the installation information provided with the inverter		
	indicates the restriction for use in a closed electrical		
	operating area, and		
	Installation information indicates what forms of shock		N/A
	hazard protection are and are not provided integral to the		
	inverter, in accordance with 5.3.2.7.		
	The inverter shall be marked as in 5.2.2.6.		N/A
5	MARKING AND DOCUMENTATION		Р
5.1	Marking		Р
	·		



	IEC 62109-2		
Clause	Requirement + Test	Result - Remark	Verdict

5.1.4	Equipment ratings	Р
	PV input ratings:	Р
	- Vmax PV (absolute maximum) (d.c. V)	Р
	- Isc PV (absolute maximum) (d.c. A)	Р
	a.c. output ratings:	Р
	- Voltage (nominal or range) (a.c. V)	Р
	- Current (maximum continuous) (a.c. A)	Р
	- Frequency (nominal or range) (Hz)	Р
	- Power (maximum continuous) (W or VA)	Р
	- Power factor range	Р
	a.c input ratings:	N/A
	- Voltage (nominal or range) (a.c. V)	N/A
	- Current (maximum continuous) (a.c. A)	N/A
	- Frequency (nominal or range) (Hz)	N/A
	d.c. output ratings:	N/A
	- Voltage (nominal or range) (d.c. V)	N/A
	- Current (maximum continuous) (d.c. A)	N/A
	Protective class (I or II or III)	P
	Ingress protection (IP) rating per part 1	P
	An inverter that is adjustable for more than one nominal	N/A
	output voltage shall be marked to indicate the particular	1071
	voltage for which it is set when shipped from the factory.	
5.2	Warning markings	Р
5.2.2	Content for warning markings	P
5.2.2.6	Inverters for closed electrical operating areas	P
<u> </u>	Where required by 4.8.3.6, an inverter not provided with	P
	full protection against shock hazard on the PV array shall	
	be marked with a warning that the inverter is only for use	
	in a closed electrical operating area, and referring to the	
	installation instructions.	
5.3	Documentation	Р
5.3.2	Information related to installation	Р
5.3.2.1	Ratings. Subclause 5.3.2 of Part 1 requires the documentation to include ratings	Р
	information for each input and output. For inverters this information shall be as in	
	Table 33 below. Only those ratings that are applicable based on the type of inverter	
	are required.	
	PV input quantities :	Р
	- Vmax PV (absolute maximum) (d.c. V)	Р
	- PV input operating voltage range (d.c. V)	Р
	- Maximum operating PV input current (d.c. A)	Р
	- Isc PV (absolute maximum) (d.c. A)	Р
	- Isc PV (absolute maximum) (d.c. A)	Р
	- Max. inverter backfeed current to the array (a.c. or	Р
	d.c. A)	
	a.c. output quantities:	Р
	- Voltage (nominal or range) (a.c. V)	Р
	- Current (maximum continuous) (a.c. A)	Р
	- Current (inrush) (a.c. A, peak and duration)	Р
	- Frequency (nominal or range) (Hz)	Р
	- Power (maximum continuous) (W or VA)	Р
		Р



	IEC 62109-2				
Clause	Requirement + Test	Result - Remark	Verdict		
	 Maximum output fault current (a.c. A, peak and duration or RMS) 		Р		
	- Maximum output overcurrent protection (a.c. A)		Р		
	a.c. input quantities:		N/A		
	- Voltage (nominal or range) (a.c. V)		N/A		
	- Current (maximum continuous) (a.c. A)		N/A		
	- Current (inrush) (a.c. A, peak and duration)		N/A		
	- Frequency (nominal or range) (Hz)		N/A		
	d.c input (other than PV) quantities:		Р		
	- Voltage (nominal or range) (d.c. V)		Р		
	- Nominal battery voltage (d.c. V)		Р		
	- Current (maximum continuous) (d.c. A)		Р		
	d.c. output quantities:		N/A		
	- Voltage (nominal or range) (d.c. V)		N/A		
	- Nominal battery voltage (d.c. V)		N/A		
	- Current (maximum continuous) (d.c. A)		N/A		
	Protective class (I or II or III)		P		
	Ingress protection (IP) rating per part 1		P		
5.3.2.2	Grid-interactive inverter setpoints		N/A		
	For a grid-interactive unit with field adjustable trip points,		N/A		
	trip times, or reconnect times, the presence of such controls, the means for adjustment, the factory default				
	values, and the limits of the ranges of adjustability shall				
	be provided in the documentation for the PCE or in other				
	format such as on a website.				
	Provided solution:				
	The setting of field adjustable setpoints shall be		N/A		
	accessible from the PCE				
5.3.2.3	Transformers and isolation		Р		
	whether an internal isolation transformer is provided, and if so, what level of insulation (functional, basic, reinforced, or double) is provided by that transformer. The instructions shall also indicate what the resulting installation requirements are regarding such things as earthing or not earthing the array, providing external residual current detection devices, etc.	Transformer-less inverter	N/A		
	An inverter shall be provided with information to the installer regarding:				
	- providing of internal isolation transformer		N/A		
	the level of insulation (functional, basic, reinforced, or double)		N/A		
	The instructions shall also indicate what the resulting insta regarding:	allation requirements are	Р		
	- earthing or not earthing the array	not earthing the array	Р		
	- providing external residual current detection devices	j	N/A		
	- requiring an external isolation transformer,		N/A		
5.3.2.4	Transformers required but not provided		N/A		
	An inverter that requires an external isolation transformer not provided with the unit, shall be provided with instructions that specify, and for the external isolation transformer with which it is intended to be used:				
	- the configuration type		N/A		
	- electrical ratings		N/A		
	- environmental ratings		N/A		



		· .		
		IEC 62109-2		
Clause	Requirement + Test		Result - Remark	Verdict

5.3.2.5	PV modules for non-isolated inverters	Р				
	Non-isolated inverters shall be provided with installation	Р				
	instructions that require PV modules that have an IEC					
	61730 Class A rating					
	If the maximum AC mains operating voltage is higher than	N/A				
	the PV array maximum system voltage then the					
	instructions shall require PV modules that have a					
	maximum system voltage rating based upon the AC					
	mains voltage.					
5.3.2.6	Non-sinusoidal output waveform information Grid-connection inverter.	N/A				
	The instruction manual for a stand-alone inverter not complying with 4.7.5.2 shall include	N/A				
	a warning that:					
	- the waveform is not sinusoidal,	N/A				
	- some loads may experience increased heating,	N/A				
	- the user should consult the manufacturers of the	N/A				
	intended load equipment before operating that load					
	with the inverter					
	The inverter manufacturer shall provide information regarding:					
	- what types of loads may experience increased	N/A				
	heating					
	- recommendations for maximum operating times with					
	such loads					
	The inverter manufacturer shall specify for the waveforms as determined by the testing in					
	4.7.5.3.2 through 4.7.5.3.4.:					
	- THD	N/A				
	- slope					
	- peak voltage	N/A				
5.3.2.7	Systems located in closed electrical operating areas Not specified to be located in	N/A				
	closed electrical operating					
	area.					
	Where required by 4.8.3.6, an inverter not provided with full protection against shock					
	hazard on the PV array shall be provided with installation instructions:					
	- requiring that the inverter and the array must be					
	installed in closed electrical operating areas					
	- indicating which forms of shock hazard protection are	N/A				
	and are not provided integral to the inverter (for					
	example the RCD, isolation transformer complying					
	with the 30 mA touch current limit, or residual current					
	monitoring for sudden changes)					
5.3.2.8	Stand-alone inverter output circuit bonding	Р				
	Where required by 7.3.10, the documentation for an inverter shall include the following:	Р				
	- if output circuit bonding is required but is not provided	Р				
	integral to the inverter, the required means shall be					
	described in the installation instructions, including					
	which conductor is to be bonded and the required					
	current carrying capability or cross-section of the					
	bonding means;					
	- if the output circuit is intended to be floating, the	N/A				
	documentation for the inverter shall indicate that the					
	output is floating.					
5.3.2.9	Protection by application of RCD's Integrated RCM provided in	N/A				



	IEC 62109-2				
Clause	Requirement + Test Resu	It - Remark Verdict			
	Where the requirement for additional protection in 4.8.3.1 is met by requiring an RCD that is not provided integral to the inverter, as allowed by 4.8.3.4, the installation instructions shall state the need for the RCD,.	N/A			
	and shall specify its rating, type, and required circuit location	N/A			
5.3.2.10	Remote indication of faults	P			
0.0.20	The installation instructions shall include an explanation of how to properly make connections to (where applicable), and use, the electrical or electronic fault indication required by 13.9.	P			
5.3.2.11	External array insulation resistance measurement and response	N/A			
	The installation instructions for an inverter for use with ungrounde incorporate all the aspects of the insulation resistance measurem requirements in 4.8.2.1, must include:				
	- for isolated inverters: an explanation of what aspects of array insulation resistance measurement and response are not provided, and	N/A			
	an instruction to consult local regulations to determine if any additional functions are required or not;	N/A			
	for non-isolated inverters: an explanation of what external equipment must be provided in the system, and	N/A			
	- what the setpoints and response implemented by that equipment must be, and:	N/A			
	how that equipment is to be interfaced with the rest of the system.	N/A			
5.3.2.12	Array functional grounding information	N/A			
	Where approach a) of 4.8.2.2 is used, the installation instructions for the inverter shall include all of the following:				
	a) the value of the total resistance between the PV circuit and ground integral to the inverter	N/A			
	b) the minimum array insulation resistance to ground that system designer or installer must meet when selecting the PV panel and system design, based on the minimum value that the design of the PV functional grounding in the inverter was based on;	N/A			
	c) the minimum value of the total resistance R = VMAX PV/30 mA that the system must meet, with an explanation of how to calculate the total;	N/A			
	d) a warning that there is a risk of shock hazard if the total minimum resistance requirement is not met.	N/A			
5.3.2.13		-connection inverter. N/A			
	Where the approach of 4.7.5.5 is used, the installation instructions for the inverter shall include a warning that the inverter is only to be used with the dedicated load for which it was evaluated, and	N/A			
	shall specify the dedicated load.	N/A			



	IEC 62109-2		
Clause	Requirement + Test	Result - Remark	Verdict

5.3.2.14	Identification of firmware version(s)	See report BL-DG2060127- B01.	Р		
	An inverter utilizing firmware for any protective functions shall provide means to identify the firmware version.		Р		
	This can be a marking, but the information can also be provided by a display panel, communications port or any other type of user interface		Р		
7	PROTECTION AGAINST ELECTRIC SHOCK AND ENERG	Y HAZARDS	Р		
7.3	Protection against electric shock		Р		
7.3.10	Additional requirements for stand-alone inverters		Р		
	One circuit conductor bonded to earth to create a grounded conductor and an earthed system.		Р		
	The means used to bond the grounded conductor to protective earth provided within the inverter or		N/A		
	as part of the installation	External earthing needed.	Р		
	If not provided integral to the inverter, the required means shall be described in the installation instructions as per 5.3.2.8.	External earthing needed.	N/A		
	The means used to bond the grounded conductor to protective earth shall comply with the requirements for protective bonding in Part 1,		Р		
	If the bond can only ever carry fault currents in stand- alone mode, the maximum current for the bond is determined by the inverter maximum output fault current.		N/A		
	Output circuit bonding arrangements shall ensure that in any mode of operation, the system only has the grounded circuit conductor bonded to earth in one place at a time		N/A		
	Switching arrangements may be used, in which case the switching device used is to be subjected to the bond impedance test along with the rest of the bonding path		N/A		
	Inverters intended to have a circuit conductor bonded to earth shall not impose any normal current on the bond except for leakage current.		Р		
	Outputs that are intentionally floating with no circuit conductor bonded to ground, must not have any voltages with respect to ground that are a shock hazard in accordance with Clause 7 of Parts 1 and 2.		Р		
	The documentation for the inverter shall indicate that the output is floating as per 5.3.2.8.		N/A		
7.3.11	Functionally grounded arrays		N/A		
	All PV conductors in a functionally grounded array shall be treated as being live parts with respect to protection against electric shock.		N/A		
9	PROTECTION AGAINST FIRE HAZARDS	<u> </u>	Р		
9.3	Short-circuit and overcurrent protection		P		
9.3.4	Inverter backfeed current onto the array		P		
	The backfeed current onto the array The backfeed current testing and documentation requirements in Part 1 apply, including but not limited to the following.				
	Inverter backfeed current onto the PV array maximum value		Р		



Page 16 of 23

Report No. BL-DG2060127-B01 attachment 1

		Page 16 of 23	Report No. BL-DG2060127-B01 att	achment 1	
		IEC 62109-2			
Clause	Requirement + Test		Result - Remark	Verdict	
	This inverter backfeed curren the installation instructions recurrent, in accordance with Ta	gardless of the value of		Р	
13	PHYSICAL REQUIREMENTS			Р	
13.9	Fault indication				
	Where this Part 2 requires the provided:	e inverter to indicate a fa	ult, both of the following shall be	Р	
	a) a visible or audible indica and detectable from outsi		ter, LCD panel is available for fault indication.	Р	
	b) an electrical or electronic remotely accessed and u		RS485 port are available for remoting communication	Р	
	The installation instructions si regarding how to properly ma applicable) and use the electric b) above, in accordance with	ke connections (where rical or electronic means	in	Р	



			opo == = =========================	
		IEC 62109-2		
Clause	Requirement + Test		Result - Remark	Verdict

4.4.4	TABLE: Single fault condition to be applied							
	Ambient temperature (°C)					25°C, if not stated otherwise		
	Power source for EUT: Manufacturer, model/type, output rating						, 62150H-1000S, 15kW.	_
						AC Sour	ce: 3075KVA, 75KVA.	
4.4.4.15.1	Fault-tolerance o	f residual	current	monit	toring		3073KVA, 73KVA.	
Component No.	Fault	Supply voltage (V)	Test time		se#	Fuse current (A)	Observation	
Residual	Loss / failure (R8	DC 600	10 min.	_	-		PCE didn't start to work. Relay	opened.
Current monitoring	o-c)						SD, DG, RO, NCD, NH, PEST.	
uint								
Residual	Loss / failure	DC 600	10 min.	-	-		PCE didn't start to work. Relay	opened.
Current monitoring	(R244 o-c)						SD, DG, RO, NCD, NH, PEST.	
uint								
Check that tl	ne residual curren	t monitor	ing opera	ates p	rope	rly	RCMU operates properly.	
Legend								
FID	Fault Indication				МТ		Max. Temperature	
SD	PCE Shut Down:				DG		Disconnection To Grid	
RO	Recovered to Ope single fault setting	Recovered to Operate after removing the single fault setting			NCD)	No Comp. or parts Damaged	
NH	No Hazards occurred				PES	Т	Pass the Electric Strength Test.	
BI	Basic insulation	Basic insulation			SI		Supplementary insulation	
DI	Double insulation				RI		Reinforced insulation	
FI	Functional insulation	on			o-l		over-load.	
S-C	short-circuited				о-с		open-circuited	

Supplementary information:

The electric strength test performed after fault condition test and see appended table 7.5.2 of Part1 for detailed test conditions.



		<u> </u>		
		IEC 62109-2		
Clause	Requirement + Test		Result - Remark	Verdict

4.4.4	TABLE: Single	fault con	dition to l	be appl	lied			Р
	Ambient tempe	rature (°C	;)			25°C, if r	not stated otherwise	_
	Power source f					DC Sour	ce:	_
	model/type, out	model/type, output rating				Chroma,	62150H-1000S, 15kW.	
						AC Sour	ce:	
						Kewell, ł	KACM-75-33, 75KVA.	
4.4.4.15.2	Fault-tolerance	of autom	atic disc	onnect	ing	means		
Component No.	• • • • • • • • • • • • • • • • • • • •		#	Fuse current (A)	Observation			
Relay function	Loss / failure	DC 600	10 min.				PCE didn't start to work. Relay	opened.
checking	(RL1 s-c)						SD, DG, RO, NCD, NH, PEST.	
Relay function	Loss / failure	DC 600	10 min.				PCE didn't start to work. Relay	opened.
checking	(RL2 s-c)						SD, DG, RO, NCD, NH, PEST.	
	e relays fulfil the sed on the PV ci				le		Relays fulfil the basic insulation separation.	or simple
Each active p	hase can be swit	ched. (L a	and N)				All pole disconnection.	
Legend								
FID	Fault Indication			N	MT		Max. Temperature	
SD	PCE Shut Down:				OG		Disconnection To Grid	
	Recovered to Ope single fault setting	rate after	removing	the	NCD)	No Comp. or parts Damaged	
NH	No Hazards occur	red		F	PES	Т	Pass the Electric Strength Test.	=
BI	Basic insulation	Basic insulation			SI		Supplementary insulation	
DI	Double insulation			F	રા		Reinforced insulation	
FI	Functional insulati	on		C	o-l		over-load.	
S-C	short-circuited			C	o-c		open-circuited	

Supplementary information:

The electric strength test performed after fault condition test and see appended table 7.5.2 of Part1 for detailed test conditions.



		IEC 62400.2		
		IEC 62109-2		
Clause	Requirement + Test		Result - Remark	Verdict

4.4.4.17	Cooling system fainlure – Blanketing	g test		P
	Test voltage (Vdc):	600		_
	Test current (Idc)	34		_
	Test voltage (Vac):	230		_
Test current (lac)		30	_	
	t _{amb1} (°C):	See below. See below.		_
	t _{amb2} (°C):			_
maximum temperature T of part/at::		T (°C)		T _{max} (°C)
1	. Ambient	50	60	
2	. DC terminals	67.6	72.6	80
3	. AC terminals	69.0	76.0	95
4	. Enclosure outside near panel (non-metallic)	73.2	78.3	85
5	Enclosure outside near inverter inductor (metallic)	71.9	82.1	90
		71.7	76.2	90

4.7.4	TABLE: Steady state Inverter AC output voltage and frequency				
	Nominal DC input (V)	600		
	Nominal output AC v	oltage (V):	230		
AC output U (V)	Frequency (Hz)	Condition/status	Comments		
230.2	50.01	Without load	Р		
229.5	50.00	Resistive load application	Р		
230.3	50.01	Resistive load removal	Р		

4.8.2	TABLE: Array insulation resistance detection for inverters for ungrounded and functionally grounded arrays					Р
4.8.2.1	Array	insulation resistanc	e detection for invert	ers for ungrounded	arrays	Р
minimum ope	DC Voltage below minimum operating voltage operation operation and PV input resistance				tification	
	DC+					



		<u> </u>		
		IEC 62109-2		
Clause	Requirement + Test		Result - Remark	Verdict

4.8.2	TABLE: Array insulation resistance detection for inverters for ungrounded and functionally grounded arrays	Р
4.8.2.1	Array insulation resistance detection for inverters for ungrounded arrays	Р

DC Voltage for inverter begin operation (V)	Resistance between ground and PV input terminal (Ω)	Required Insulation resistance R = (V _{MAX PV} / 30mA) (Ω)	Identification
180	I.F.	32.3	I.F.: Isolation Failure
180	I.F.	32.3	N.O.: Normal Operation
180	I.F.	33.3	
180	I.F.	33.3	
180	N.O.	34.3	
180	N.O.	34.3	
	DC-		•
180	I.F.	32.3	I.F.: Isolation Failure
180	I.F.	32.3	N.O.: Normal Operation
180	I.F.	33.3	
180	I.F.	33.3	
180	N.O.	34.3	
180	N.O.	34.3	
	180 180 180 180 180 180 180 180 180 180	inverter begin operation (V) between ground and PV input terminal (Ω) 180 I.F. 180 I.F. 180 I.F. 180 I.F. 180 N.O. DC- I.F. 180 I.F.	Insulation resistance R = (V _{MAX PV} / 30mA) (Ω)

Note:

For isolated inverters, shall indicate a fault in accordance with 13.9 (operation is allowed); the fault indication shall be maintained until the array insulation resistance has recovered to a value higher than the limit above

For non-isolated inverters, or inverters with isolation not complying with the leakage current limits in the minimum inverter isolation requirements in Table 30, shall indicate a fault in accordance with 13.9, and shall not connect to the mains; the inverter may continue to make the measurement, may stop indicating a fault and may connect to the mains if the array insulation resistance has recovered to a value higher than the limit above.

It is not required to test all PV input terminals if analysis of the design indicates that one or more terminals can be expected to have the same result, for example where multiple PV string inputs are in parallel.

Supplementary information:

1) I.F. (FID: Isolation Failure)

2) Array Insulation Resistance Threshold Value R = 33.3 [k Ω] (should be larger than R=VMAX PV / 30mA) Ω .

4.8.3.2 T	ABLE: 30mA touch	current type test for isolated invert	ers	N/A
Con	dition	Current (mA)	Limit (30mA)	
DC+	to PE			
DC-	to PE	-		
Supplementary inf Non-isolated type				



		<u> </u>		
		IEC 62109-2		
Clause	Requirement + Test		Result - Remark	Verdict

4.8.3.3	TABLE: Fire hazard	ABLE: Fire hazard residual current type test for isolated inverters				
Condition		Current (mA)	Limit (300mA or 10mA per kVA)			
DC+ to PE						
DC- to PE						
Supplementary information: Non-isolated type inverter.						

4.8.3.5 TABLE: Protection by residual current monitoring

Output power (kVA): 5kW
Input voltage (V_{DC}): 500Vdc
Frequency (Hz) 50Hz
Output AC Voltage (V_{AC}): 400Vac

4.8.3.5.2	Fault Current (mA) Disconnection time (ms)						
	Limit 300mA for output power ≤ 30	Disconnection time (ms	5)				
Measured Fault Current	kVA 10mA per kVA for output power > 30 kVA	Measured Disconnection time	Limit				
	+	- PV to N:					
287.4 300		32.0	300				
287.4	300	83.0	300				
287.4	300	60.0	300				
287.4	300	44.0	300				
287.4	300	92.0	300				
		- PV to N:					
296.4	300	34.0	300				
296.4	300	57.0	300				
296.4	300	49.0	300				
296.4	300	41.0	300				
296.4	300	54.0	300				

Note

- maximum 300mA for inverters with continuous output power rating ≤30 kVA;
- maximum 10mA per kVA of rated continuous output power for inverters with continuous output power rating > 30 kVA.

This test shall be repeated 5 times, and for all 5 tests the time to disconnect shall not exceed 0,3s.

The test is repeated for each PV input terminal. It is not required to test all PV input terminals if analysis of the design indicates that one or more terminals can be expected to have the same result, for example where multiple PV string inputs are in parallel.

Supplementary information:



•	+PV to N	
	UN	Limit
Limit (mA)	Disconnection time (ms)	(ms)
30	152	300
30	150	300
30	148	300
30	158	300
30	148	300
60	86	150
60	78	150
60	86	150
60	84	150
60	86	150
150	26	40
150	27	40
150	22	40
150	20	40
150	29	40
	-PV to N	
Limit (mA)	U _N	Limit
	Disconnection time (ms)	(ms)
30	148	300
30	158	300
30	152	300
30	150	300
30	148	300
60	84	150
60	86	150
60	84	150
60	86	150
60	86	150
150	27	40
150	27	40
150	22	40
150	20	40
150	26	40

Note:

The capacitive current is raised until disconnection.

Test condition: I_c + 30/60/150mA <= I_{cmax} . R_1 is set that 30/60/150mA Flow and switch S is closed.

Supplementary information:

100% output power and Vmppmax input voltage



List of test equipment used:

	1			T	1
No.	Equipment name	Manufacture	Serial No.	Calibration Data	Usage
1	Simulation of ac power supply	WLPA-33-1000KVA	BZ-DGD-L001		√
2	Solar IV simulator	WDGC-1000KW	BZ-DGD-L002		$\sqrt{}$
3	Programmable ac load	ACLT-38160H	BZ-DGD-L003		√
4	Power analyser	PW6001-16	BZ-DGD-L025	2021\3\04	\checkmark
5	Oscilloscope	MSO4054B	BZ-DGD-L028	2021\3\04	√
6	Heating Recorder	LR8400-21	BZ-DGD-L032	2020\8\28	√
7	Hi-Pot & IR tester	Chroma 19032	BZ-DGD-L066	2021\3\04	√
8	Noise meter	TES-1357	BZ-DGD-L029	2021\3\06	√
9	Digital Caliper	LS160	BZ-DGD-L048	2020\07/02	√
10	Testing Finger B	AUTO-B	BZ-DGD-L011	2020\11\1	√
11	DC Electronic Load	IT8511+	BZ-DGD -L027	2020\10\31	√
12	Pull and push	2P-1000	BZ-DGB-L080	2020\8\28	√
13	Electronic Scale	TCS-300	BZ-DGB-L020	2020\07/02	√
14	Thermostat	16m³	BZ-DGD-L015	2020\07/02	√
15	Surge generator	HCWG 70	BZ-DGE-L036	2021\5\5	√
16	Solar IV simulator	62150H-1000S	BZ-DGD-L009		√
17	Simulation of ac power supply	KACM-75-33	BZ-DGD-L193		√

⁻ End of test report -